## Appendix K.

## Validation Criteria for Air Monitoring Data

### **Validation Criteria for Air Monitoring Data**

Air Quality Monitoring Program Yerington Mine, Yerington, Nevada

				LCS Conti	rol Limits
Parameter	Method	PQL <sup>(1)</sup> (µg)	MDL (µg)	Recovery (%)	RPD <sup>(2)</sup> (%)
PM <sub>10</sub>	EPA IO-2.1	100	N/A	N/A	N/A
Arsenic	SW846-6020	2.0	0.50	75-125	20
Barium	SW846-6020	1.0	0.50	75-125	20
Cadmium	SW846-6020	1.0	0.20	75-125	20
Chromium	SW846-6020	2.0	0.50	75-125	20
Lead	SW846-6020	1.0	0.20	75-125	20
Mercury	SW846-7471A	0.2	0.0001	75-125	20
Selenium	SW846-6020	2.0	0.15	75-125	20
Silver	SW846-6020	1.0	0.20	75-125	20

		MDA
Parameter	Method	(pCi)
Thorium (228, 230, 232)	HASL-300	1.008
Radium 226	EPA 903.1M	1.008
Radium 228(b)	EPA 904.0M	3.12
Gross Alpha	HASL-300	19.92
Gross Beta	HASL-300	0.6
Uranium (234, 235, 238)	HASL-300	1.008

### Notes:

(1) = maximum acceptable PQL

(2) = RPD limit includes laboratory duplicates

LCS = laboratory control sample

MDA = minimum detectable activity are isotope dependent based on a 60 min counting time.

MDL = method detection limit

 $\mu g = microgram$ 

N/A = not applicable

pCi = picoCuries

PQL = practical quantitation limit

RPD = relative percent difference

# METHOD 6020 METALS ANALYSES QA/QC CRITERIA

QUALITY PARAMETER	METHOD/ FREQUENCY	CRITERIA	CORRECTIVE ACTION
Instrument Tune	Daily, prior to calibration and sample analysis	Mass resolution < 1.0 amu @ 10% peak height and mass calibration 0.1 amu.	Retune instrument. Repeat tune solution and analysis.
Initial Calibration	Laboratory mixed standard calibration	Correlation coefficient: 0.995	Evaluate system. Recalibrate.
Calibration Blank	After initial calibration and each continuing calibration	< PQL	Rerun. Clean system. Reanalyze affected samples.
Initial Calibration Verification (ICV)	After calibration	10% of expected response	Reanalyze ICV. Recalibrate.
Continuing	Every 10 samples	10% of expected response	Reanalyze.
Calibration Verification (CCV)	and end of run sequence	· · · · · · · · · · · · · · · · · · ·	Recalibrate. Reanalyze samples.
Method Blank	1 per analytical batch	<pql (rl)<="" td=""><td>Reanalyze. Recalibrate as necessary.</td></pql>	Reanalyze. Recalibrate as necessary.
Internal Standard	Each sample	30-130 %	Reanalyze and/or narrate.
Duplicate Control Sample (DCS)	1 per analytical batch	See included table for specific analytes	Check calculations. Assess impact on data. Narrate.
TY 11:			
Holding Time		Days to analysis: 180	

# STL Reference Data Summary

Units Run Date ug 19980609 ug 19980609 ug 19980609 ug 19980609		Matr Extractic Metho QC Progratic Locatio  Check List 20  T A Amt Units  C Y 1000 ug C Y 200 ug C Y 200 ug	Mat Extractii Meth QC Progra Locati  Check List 2  T A Amt Units C Y 1000 ug C Y 200 ug C Y 200 ug
·	19980609 19980609	Matr Extractic Methor QC Program Locatio Check List 20  The State T A Amt Units  19980609 C Y 1000 ug 19980609 C Y 200 ug 19980609 C Y 200 ug	Matrix: Extraction: Method: I CC Program: / Location: S Check List 20962  its Run Date T A Amt Units LCL U 19980609 C Y 1000 ug 78 1 19980609 C Y 200 ug 82 10 19980609 C Y 200 ug 82 10

## **METHOD 7471A (Mercury) QA/QC CRITERIA**

QUALITY PARAMETER	METHOD/ FREQUENCY	CRITERIA	CORRECTIVE ACTION
Initial Calibration	Blank and five standards. Daily before analysis	Correlation Coefficient 0.995	Evaluate system. Recalibrate.
Calibration Blank	After initial calibration and each calibration	< PQL <sup>1</sup>	Rerun. Clean system. Reanalyze affected samples.
ICV	After calibration	80-120%	Reanalyze ICV. Recalibrate.
CCV	Every 10 samples and end of run sequence	80-120%	Reanalyze. Recalibrate. Reanalyze affected samples.
Method Blank	1 per analytical batch	< PQL <sup>1</sup>	Reanalyze. Recalibrate as necessary. Reanalyze.
Duplicate Control Sample (DCS)	1 per analytical batch	80-120% (aqueous)	Check calculations. Re-extract and reanalyze as necessary. Assess impact on data. Narrate.
Holding Time		Days to analysis: 28	

The term PQL refers to the laboratory's standard Reporting Limit.

# STL Reference Data Summary

<b>Sy</b>	<u></u>
Analyte List Syn Compound 1701 Mercury	Structured Analysis Code: S-2A-O9-3W-07 Target Analyte List: All Analytes
0.2	S-2A-O9-3W. All Analytes
Detection Limits Units MDL ug 0.00	-07
MDL Units 0.00006 ug	
Run Date 19980126	
Check List 20978  T A Amt Units LCL UCL RPD T A Amt Units LCL UCL RPD C Y 3.0 ug 80 120 20 C Y 3.0 ug 80 120 20	Matrix: AIR  Extraction: PM-10 Filter Metals Digestion  Method: Mercury (7471A, Cold Vapor) - Solids  QC Program: AMBIENT AIR TESTING  Location: STL Sacramento

### Appendix L.

### Validation Criteria for Meteorological Data

### Variable

# Screening Criteria (flag data if the value meets one of the following)

Wind Speed	<ul> <li>Less than zero or greater than 25 meters per second (m/s)</li> </ul>
	<ul> <li>Does not vary by more than 0.1 m/s for 3 consecutive hours</li> </ul>
	<ul> <li>Does not vary by more than 0.5 m/s for 12 consecutive hours</li> </ul>
Wind Direction	<ul> <li>Less than zero or greater than 360°</li> </ul>
	<ul> <li>Does not vary by more than 1 degree for more than 3</li> </ul>
	consecutive hours
	<ul> <li>Does not vary by more than 10 degrees for 18 consecutive</li> </ul>
	hours
Temperature	<ul> <li>Greater than the local record high</li> </ul>
	<ul> <li>Less than the local record low</li> </ul>
	<ul> <li>Greater than a 10 °C change from the previous hour</li> </ul>
	<ul> <li>Does not vary by more than 0.5 °C for 12 consecutive hours</li> </ul>
Solar Radiation	Greater than zero at night
	<ul> <li>Greater than the maximum possible for the date and latitude</li> </ul>
Barometric Pressure	<ul> <li>Greater than the local record high</li> </ul>
	<ul> <li>Less than the local record low</li> </ul>
Humidity	<ul> <li>Less than 30% during precipitation events</li> </ul>
	<ul> <li>Varies by 30% of the local average for 24 consecutive hours</li> </ul>